

***W*itsee.**

Safety and warranty guide



Important safety information

Witsee Sensor is intended solely for measuring bowling throw data. Do not use the product for any other purpose.

Handle Witsee sensor with care. It contains sensitive electronic components, including batteries, and can be damaged, impair functionality, or cause injury if dropped, burned, punctured, crushed, disassembled, or if exposed to excessive heat or liquid or to environments having high concentrations of industrial chemicals.

Do not use a damaged Witsee sensor.

Battery

Witsee sensor contains a coin cell battery. The battery may need to be replaced during the life of the product. Replace only with the same type (CR1025) and rating of battery, observing the correct polarity.

To replace the battery:

1. Use the screwdriver included in the Witsee kit.
2. Select the battery replacement tool located in the center of the screwdriver and pull it out.
3. Insert the battery replacement tool into the opening on the Witsee sensor.
4. Gently twist the tool sideways to release and open the sensor cover.
5. Once the lid is open, use the tool to carefully push the battery until you can remove it.
6. Insert a CR1025 battery into the device with the positive side (+) facing up
7. Close the sensor lid by pressing it firmly back into place until it is fully secured.

Replacing the battery with an incorrect type may result in battery leakage, overheating, fire, or explosion. Use only a CR1025 battery or an equivalent battery recommended by Witsee.

Important: Dispose of used battery according to your local

environmental laws and guidelines.

Keep batteries away from children. Do not ingest battery, if ingested or placed inside body seek medical attention immediately. Ingesting can cause severe chemical burns in just two hours and result in serious injury or death. If the battery compartment does not close securely, stop using the device and keep away from children.



WARNING: Do not ingest battery; chemical burn hazard.

Bluetooth

This product contains a Bluetooth Low Energy radio transmitter operating in accordance with applicable regulations.

Choking hazard

Witsee sensor, the battery compartment door, the battery, and case may present a choking hazard or cause other injury to small children. Keep these items away from small children.

Medical device interference

Witsee sensor contains radio transmitters and other components that generate electromagnetic fields. These electromagnetic fields may interfere with pacemakers, defibrillators, or other medical devices. Maintain a safe distance of separation between your medical device and Witsee sensor. Consult your physician and medical device manufacturer for information specific to your medical device. Stop using Witsee sensor if you suspect it is interfering with your pacemaker, defibrillator, or any other medical device.

Electrostatic shock

To reduce the risk of electrostatic discharge, avoid handling the sensor in extremely dry environments whenever possible.

Important handling information

Don't press anything sharp on the battery terminal contacts inside the Witsee sensor. Do not immerse the sensor in water or other liquids. Clean only with a soft, dry cloth. Do not use solvents, alcohol, aerosol sprays, or abrasive cleaners.

Support

For support, troubleshooting information, FAQs, and software updates, visit: www.witsee.com

Regulatory Compliance Information

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- If the equipment is connected to an outlet, connect it

to an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this product not authorized by Witsee could void the electromagnetic compatibility (EMC) and wireless compliance and negate your authority to operate the product.

This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices. It is important that you use compliant peripheral devices to reduce the possibility of causing interference to radios, televisions, and other electronic devices. This product was tested for EMC compliance under conditions that included the use of Witsee peripheral devices.

Responsible party (contact for FCC matters only):

Witsee Tech UAB

P. Lukšio g. 5-1

LT-08221 Vilnius

Lithuania

support@witsee.com

EU Compliance

Hereby, Witsee Tech declares that the radio equipment type Witsee Sensor is in compliance with Directive 2014/53/EU.

A copy of the EU Declaration of Conformity is available at www.witsee.com/compliance

Responsible party:

Witsee Tech UAB

P. Lukšio g. 5-1

LT-08221 Vilnius

Lithuania



United States: The symbol above indicates that this product and/or battery should not be disposed of with household waste. When you decide to dispose of this product and/or its battery, do so in accordance with local environmental laws and guidelines.

Declaration of Conformance

This product complies with Reduction of Hazardous Substances (RoHS) requirements. Further information on regulated substances and constituents can be found in Witsee Regulated Substances Specification at www.witsee.com/compliance

Frequency	Maximum Power
2.4GHz (Bluetooth®)	100 mW

Battery Disposal Information

California: The coin cell battery in your device contains perchlorates. Special handling and disposal may apply. Refer to dtsc.ca.gov/hazardouswaste/ perchlorate.

Disposal and Recycling Information



European Union: The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Witsee Two-Year Limited Warranty

Witsee Tech, UAB warrants the Witsee Sensor and the accessories included in the original package against defects in materials and workmanship for a period of two (2) years from the date of the original retail purchase.

This Limited Warranty covers manufacturing defects that occur during normal and intended use of the product. It does not cover:

- normal wear and tear;
- cosmetic damage that does not affect product functionality;
- damage caused by improper installation, misuse, abuse, neglect, accident, modification, or unauthorized repair;
- damage resulting from use contrary to the instructions provided by Witsee;
- damage caused by external factors such as fire, flooding, excessive moisture, chemicals, or other environmental conditions;
- consumable items or accessories that naturally wear over time, unless the failure has occurred due to a manufacturing defect;
- damage caused by normal battery depletion or batteries supplied by third parties.

If you believe your product has a defect covered by this Limited Warranty. Before returning any product, please contact Witsee by:

emailing support@witsee.com, or

submitting a support request at www.witsee.com/support.

When submitting a warranty claim, you may be required to provide:

- proof of purchase;
- a description of the issue;
- photographs or videos demonstrating the problem; and
- any additional information reasonably requested to evaluate the claim.

If Witsee determines that the product is covered by this Limited Warranty, Witsee will, at its sole discretion:

- replace the product with the same or an equivalent product;
- refund the original purchase price.

This Limited Warranty applies only to products purchased through Witsee or an authorized Witsee reseller.

For consumers in the European Union, European Economic Area EEA, Switzerland, and the United Kingdom, this Limited Warranty is provided in addition to, and does not affect, any statutory consumer rights available under applicable consumer protection laws. In particular, consumers may have legal rights against the seller in the event of a lack of conformity, which remain unaffected by this Limited Warranty.

This Limited Warranty is non-transferable and applies only to the original purchaser unless otherwise required by applicable law.

support@witsee.com

www.witsee.com/support

www.witsee.com

